

## FREQUENTLY ASKED QUESTION

- Q:** How can I add my city if it is not listed in the watch?  
**A:** You can set any location around the world by using the latitude and longitude coordinates (see page 12).
- Q:** Azan times are not correct. Why?  
**A:** Make sure you have correctly set your city and the Gregorian calendar. If Azan times are shifted by one hour, make sure to correctly set the **DST** option.
- Q:** Azan times for Fajr, Asr and/or Isha are not correct. Why?  
**A:** There are different methods to calculate these azan times. Make sure to select a suitable taqweem system (see page 13).


## INDEX

Main Menu .....	1	Adding a New City .....	12
Setting Time, Calendar & City ...	3	Taqweem Selection .....	13
Setting Hijri Calender .....	5	Safety Time Adjustment .....	14
Setting Prayer Alarms .....	6	Qibla Direction .....	15
Advanced Menu: .....	7	Moon Age .....	16
Alarm 1, Alarm 2, Language Selection, Main Calender, Time Display, DST Selection, Stop Watch, Volume control		Quran Bookmark .....	16
		Frequently Asked Question ...	17

1

## MAIN MENU

### Main Screen



Time, calendar, & azan time

Day of the week and Hijri calendar

Fajr azan

Shuroq

**NOTE** To set the time, Gregorian calendar and your city, press and hold **Set** for two seconds at main screen. Similarly, to set Hijri calendar or any prayer alarm, move to the desired screen then press **Set** for two seconds.

2

## MAIN MENU (Cont.)



Zuhr azan

Asr azan

Magrib azan

Isha azan

**NOTE** The watch will automatically return to the main screen if no button is pressed for few seconds.

3

## Setting Time, Calendar and City

### Main Screen



Press & hold set for 2 seconds to enter setting

Adjust hours\* using + or - then press Set

Adjust minutes\*\* using + or - then press Set

Adjust day using + or - then press Set

\* When setting hours, notice the flashing AM/PM icons.

\*\* After changing the minutes, the seconds will restart counting from 00

4

## Setting Time, Calendar, and City (Cont.)



Adjust month using + or - then press Set

Adjust year using + or - then press Set

Select your city\* using + or - then press Set

Qibla\*\* direction and angle

\* Refer to page 12 to add any non-listed location.


\*\* In this example, after selecting DUBAI city, the watch will display the Qibla direction (**WEST**) and the Qibla angle (257° clockwise from North direction).

5

### SETTING HIJRI CALENDAR

After setting Gregorian date, the Hijri date is automatically adjusted according to the astronomical moon sighting at Makkah.

When needed, you can change Hijri date by first moving to Hijri calendar screen (by pressing +), then following the steps below:



Press & hold set for a while to enter setting

Adjust day using + or - then press set

Adjust month using + or - then press set

Adjust year using + or - then press set

**NOTE** Gregorian date is not affected by Hijri date setting.

6

### SETTING PRAYER ALARMS

Prayer alarms are useful as reminders of Iqama or Salat time. Each prayer alarm can be set to ring before or after the azan time by a fixed interval. Moreover, each alarm duration can be adjusted (in seconds), or can be turned OFF. The icon ☺ near the azan time indicates that the prayer alarm is ON (for that particular azan).

**Example:** To set Zuhr prayer alarm to always ring after the azan by 10 minutes, move to Zuhr azan screen, then:



Press & hold set to enter setting

Adjust hours then press set

Adjust minutes then press set

Adjust duration (or OFF)

**NOTE** In the watch default setting, each prayer alarm rings exactly at its corresponding azan time.

7

### ADVANCED MENU

Main screen



Press and hold + to get to the Advanced Menu

Daily alarm 1

Daily alarm 2

Qibla direction



Battery level

Alarms volume control

Stop watch

Daylight saving time selection

### ADVANCED MENU (Cont.)

8



Language selection (English or Arabic)

Main calendar (Hijri or Gregorian)

Time display Option 12 / 24



Azan safety times

Azan taqweem systems

Either Azan time or Prayer Period

9

### ADVANCED MENU DESCRIPTION



Alarm 1 and Alarm 2 are general purpose daily alarms. Their setting is similar to the prayer alarms setting (page 6). The (☉ icon [or ☺]) indicates that alarm1 [or alarm2] is ON.



Qibla direction can be determined relative to North or to the current Sun/Moon positions (see page 15). This screen also displays the Moon age (see page 16).



Language selection: English or Arabic.



You can select the Gregorian or Hijri calendar to be displayed in the main screen.

### ADVANCED MENU DESCRIPTION (Cont. 1)

10



Time can be displayed in either 12 hours (AM/PM) format or 24 hours format. Time can also be displayed with or without the running seconds.



The watch can be set to display "Prayer Interval" instead of "Azan time". When "Prayer Interval" is selected, the watch will display the number of minutes after the current azan (up to 30 minutes).



The watch uses the local (or the most widely used) taqweem system in your city. As needed, other taqweem systems can be selected (see page 13).



Azan safety time adjustment, see page 14.

11

**ADVANCED MENU DESCRIPTION (Cont. 2)**

DST SEL

Daylight Saving Time ( DST ) selection. When DST is ON, all azan times and current time increases by one hour.

STOP-W

Stop Watch with accuracy 0.1 seconds. Press **SET** to enter and exit, press + to Start/Stop, and press - to reset to 00:00

VOLUME

02

Two volume levels (for all alarms): 2 is High, 1 is Low, or OFF.



The expected battery life is about one year. When battery becomes low (  ), replace with CR2025 battery. Actual battery level (in Volts) can be displayed by pressing **SET**

12

**ADDING A NEW CITY**

Any location around the world can be added using latitude, longitude and GMT information. For example, the following steps show how to set the city of Lausanne in Switzerland:

Located on Latitude **46° 31 N** and Longitude **6° 36 E**, and **GMT+1:00**:

- 1/ Follow the steps on pages 3 and 4 to get to city selection
- 2/ Press + or - to choose **NEW CITY** then press **SET**
- 3/ Adjust latitude ( 4 6 N ), press **SET**, adjust minutes ( 31 ), then press **SET**
- 4/ Adjust longitude ( 6 E ), press **SET**, adjust minutes ( 36 ), and press **SET**
- 5/ Adjust **GMT (+1:00)** then press **SET**
- 6/ Adjust daylight saving time ( DST ) ON or OFF then press **SET**

The default taqweem system is **MSLM LG**. As needed, other taqweem systems can be selected (see page 13).

For more information, please visit: [www.alfajr.com/newcity](http://www.alfajr.com/newcity)

**NOTE** If azan times are not correct, check the following: city's coordinates, Gregorian date, DST option, and the appropriate taqweem system.

13

**TAQWEEM SELECTION**

This watch is already programmed to use the local (or the most widely used) taqweem system for your city. But, to select another taqweem follow the steps below:

- 1/ Move to **TAQWEEM** screen in the advanced menu (see pages 7 & 8)
- 2/ Press and hold **SET** for two seconds to enter setting mode
- 3/ Use + or - to select the desired taqweem, then press **Set** to confirm

**Main taqweem systems:**

<b>UMAIQURA</b>	Saudi system
<b>MSLM LG</b>	World Muslim League
<b>ISNA</b>	Islamic Society of North America
<b>HANFI</b>	Islamic Scientific University (Karachi)
<b>EGYPT</b>	Egypt system
<b>FIXED 1:30</b>	Isha is 1:30 after Magrib and Fajr 1:30 before Shuroq

**NOTE** After changing the city, the original taqweem for this city will be used.

14

**SAFETY TIME ADJUSTMENT**

As needed, any azan time can be adjusted forward or backward by a fixed number of minutes, as follows:

- 1/ Move to **AZHAN SAFETY** screen in the advanced menu (ages 7 & 8)
- 2/ Press **SET** for two seconds to enter setting mode
- 3/ Use + or - to adjust safety time of Fajr azan then press **Set**
- 4/ Repeat the above step, as desired, for the other azan times

**NOTE** Safety times are re-set after selecting another taqweem or city.


15

**QIBLA DIRECTION**

The watch displays Qibla direction relative to North or current Sun/Moon positions, as follows:

- 1/ Move to **QIBLA** screen (see pages 7 & 8)
- 2/ Press **SET** for two seconds
- 3/ Press " + " to display Qibla direction from North ( **N** ) or from Sun (  ) or from Moon (  ).
- 4/ Point the right side arrow  towards the North, Sun\* or Moon. In this position, the left side arrow  will point to Makkah direction.

\* In this case, it is easier to utilize the Sun shade.



Example

**NOTE** Qibla direction can always be determined relative North. And it can be determined relative to Sun position (only at daytime) and to Moon position (only at night time). The  icon indicates that the Qibla direction is not available at this time.

16

**MOON AGE**

MOON AGE  
3 d  
18 h

This screen displays the Moon age (in days and hours), where the symbol "d" indicates days and the "h" indicates hours. In this example, the current astronomical Moon age is 3 days and 18 hours. You can reach this screen after displaying Qibla direction (see page 15).

**QURAN BOOKMARK**

سورة البقرة  
255  
3

Quran bookmark screen displays the last Sura name and Aya number read. To reach this screen, press + then again press and hold + for 2 seconds.

To change the bookmark, use + or -

**NOTE**

The Aya number is displayed at the middle of the screen, and the Jouza number is displayed at the bottom of the screen.