



INFORMATION MENU (Cont1)

DUHR

11:46

Dhuhr azan time.

From this screen, you can set Dhuhr alarm.

⋮
↓

ISHA

7:55

Isha azan time.

From this screen, you can set Isha alarm.

Note: After waiting for few seconds, the watch will display the "Midnight" time.

FAJR

3:40

Fajr azan time.

From this screen, you can set Fajr alarm.

Note: After waiting for few seconds, the watch will display the time of the "last third of the night".

QURAN BO From the "Quran Bookmark" screen you can set the Sura name and Aya number, you have last read. Note: Aya & Jouza numbers are displayed at the Middle & Bottom of the screen.

SHORT CU From main screen, you can press & hold  to quickly shortcut to Qibla screen. This shortcut can be changed to another screen, as per your need and ease of use of your watch.

WWW.ALFA Website : www.alfajr.com

To display battery level in VOLTS, press and hold

MON → DAY → SAFAR → YEAR

Adjust year
then press 

NOTE Note that after setting the Gregorian date, the Hijri date is automatically adjusted according to Um Alqura calendar.

Overview	1	Time & Calendar Setting	13
Information Menu*	3	Hijri Calendar Setting	14
City Selection	10	Prayer Alarms Setting	15
Adding New City	11	Qibla Compass	16
Taqweem Selection	12	Frequently Asked Questions	18

* Main Screen, Hijri Calendar, Azans, Qibla Direction, City Select, Events, Language Selection, Hijri/Gregorian, Setting Time & Calendar, Format Time, Azan Display, Taqweem, DST Selection, Daily Alarm, Stop Watch, Volume Control, My Name, Quran Bookmark, Shortcut, Website, Battery Level.

Press & hold **QIBLA** in this screen to display Qibla or North directions, or you can calibrate the digital compass, see pages 16 & 17.

CITY From this screen you can select your city, see pages 10 & 11.

EVENTS Press & hold **11 RAMADAN 2024** to display the expected date of the coming Islamic event.

In this example, the first day in RAMADAN will be on 11/3/2024. Press **11-03-2024** to see the dates of the next Islamic events.

CITY → EGYPT → CAIRO

Press & hold **SET** → Select country* then press **SET** → Select city* then press **SET**

NOTE If azan times are not correct, make sure to correctly set: your city, Gregorian calendar, DST, and a suitable taqweem system, see page 12.

Press & hold (SET) to enter setting

Adjust minutes then press (SET)

Select number of beeps

NOTE ➤ In the watch default setting, each prayer alarm rings exactly at its corresponding azan time (two beeps/seconds).



The diagram shows a rectangular screen with a black border. Inside the screen, the text "16 JUNE" is at the top, "12:30" is in the middle, and "3:40" is at the bottom. To the right of the screen are three buttons: a plus sign (+) at the top, a button labeled "SET" in the middle, and a minus sign (-) at the bottom. Three lines point to the screen from the left: "DATE" points to the top, "TIME" points to the middle, and "NEXT AZAN" points to the bottom.

DATE —

TIME —

NEXT AZAN —

16 JUNE

12:30

3:40

+

SET

-

Press + to next screen

Press SET to enter setting mode

Press - to previous screen (in main screen, to turn light on)

Press \ominus to previous screen (in main screen, to turn light on)

عربي / ENG Language selection: English or Arabic.

HIJRI / GREGORIAN To display either the Gregorian or Hijri calendar on the main screen.

TIME 12:30 The time and calendar can be adjusted from this screen (see page 13).

FORMAT TIME You can select the time format to be either 12 hours (AM/PM) or 24 hours, and with or without seconds.

- 1) Press **+** several times until reach to **CITY** screen then press & hold **SET**
- 2) Select **USA** then press **SET**
- 3) Press **+** or **-** to choose **NEW CITY** then press **SET**
- 4) Adjust latitude (44N), press **SET**, adjust minutes (34), then press **SET**
- 5) Adjust longitude (123E), press **SET**, adjust minutes (15), then press **SET**
- 6) Adjust GMT (-8:00), then press **SET**


After above setting, this location is stored in the watch, and time of new city and new azaan times are recalculated.

For more information, please visit: alfajr.com/en/city

QIBLA → ROTATE →  → N 95° → CALIBRATE

Press & hold  to enter Rotate* 360° Arrow pointing to Qibla** Arrow pointing to North Compass* Calibration

** In Makkah city, the Qibla is displayed as (➡🕌➡).
Note that within makkah city, different locations have different Qibla directions.



Press  to next screen

Press  to enter setting mode

Press  to previous screen (in main screen, to turn light on)

Press  to display the Qibla

Press  to display the Qibla

AZAN DISPLAY The watch displays the "azan time" or "azan counter" (-59 minutes before azan to +30 minutes after azan).
You can also set your watch to display both of them, alternatively.

TAQWEEM The watch uses the local (or the most widely used) taqweem system in your country. As needed, other taqweem systems can be selected (see page 12).

When Daylight Saving Time (DST) is ON, azan times and current time are advanced by one hour. In Europe & North America, the DST is automatically adjusted (Auto DST).

- 1) Press **+** several times until reach to **TAQWEEM** screen.
- 2) Press **SET** and hold to enter setting mode.
- 3) Use **+** or **-** to select the desired taqweem, then press **SET** to confirm.

NOTE After re-selecting a country, the clock will reset the city's default taqweem (if CUSTOM taqweem was not selected).

- 1) When using digital compass, do not get close to high magnetic fields, such as electronic devices or sound speakers, etc. In addition, compass accuracy may be affected inside concrete buildings.
- 2) For more accurate direction, you can re-calibrate the compass (see **CALIBRA** screen on page 16).
In addition, the watch will automatically prompt you to re-calibrate, after you change the city or if the watch is subjected to high magnetic field.
- 3) The watch displays the True North (not the Magnetic North), as the magnetic deviation angle is automatically compensated.

5) Compass will stop after 60 seconds, or after press (SET)

16 JUNE
12:30
3:40

This is the main screen, which displays the time, date and next azan time. Press **⊕** to move to the following screens.

FRI
10:12
1445

This screen shows the day of the week and the Hijri Calendar. To adjust Hijri Calendar (if needed), press and hold **Ⓜ**.

TO FAJR
-3:10
3:40

This screen displays the time remaining to next azan. In this example, Fajr azan time is after three hours and 10 minutes.

SHUROQ
5:06

This screen displays Shuroq time. From this screen, you can set Shuroq alarm.

8

INFORMATION MENU (Cont.5)

ALARM

This is a general purpose daily alarm. Its setting is similar to that of the prayer alarms (see page 15). The **Ⓜ** icon on the main screen, indicates that the alarm is ON.

STOP WATCH


To use the Stop Watch: Press **Ⓜ** to enter and exit, press **⊕** to Start/Stop, and press **⊖** to reset to **00:00**

VOLUME

To stop all alarms sounds, you can select buzzer volume (OFF).

MY NAME

You can personalize your watch by displaying any word on the main screen. The word can be at most seven characters long.

Adjust hours then press  (Note AM/PM)

* From this screen, you can set the date that is displayed on the main screen. And to set other date (Hijri or Gregorian), see page 14.

A: You can set any location around the world by using the latitude and longitude coordinates (see page 11).

Q: Azan times are not correct. Why?

A: Make sure you have correctly set the following:

- a)** Country and City names, **b)** Gregorian calendar, **c)** DST (Daylight saving time option), and **d)** Taqweem system.

Q: How to get more accurate Qibla and North directions?

A: To get more accurate directions, recalibrate the compass (see pages 16 & 17) and avoid strong magnetic fields.